



期偉有限公司
MIRACLE CO., LTD.

ISO 9002 Certified

OFFICE: TEL:02-25940224, FAX:886-2-25944047
TAIPEI, TAIWAN
LIAISON:TEL: 04-24715429, FAX:886-4-24714429
TAICHUNG, TAIWAN
PLANT: TEL:07-3533476, FAX:886-7-3533544
KAOHSIUNG, TAIWAN
E-MAIL: miracle83@seed.net.tw

Temperature Calibration Unit [R, or S]
Type: Carbtherm

1. Operation:

1. Make sure if the unit is loaded with 9V battery and maintain over 8 volts.
2. Plug the connecting wire into Calibration unit.
3. Clip another end of connecting wire into connector of pyrometer (red clip for positive and black clip for negative).
4. Push the “temperature switch” for 5 seconds and then release. The test is finished.
(If temperature shows too much different, please check the polarity of connecting wire.).
5. Push the “test switch” for checking the battery power. If the LED light is on, then it means the batter power is OK.

2. Specification :

1. Signal output : R type 1200°C/1600°C, or
(S type 1200°C/1600°C)
2. Cold conjunction compensation : -40°C to 100°C
3. Power consumption : about 2.5mA during test.
4. Power source : 9volt battery x 1 piece.
5. Size : 65 x 115 x 35 mm (0.25kg).

